



Sprinter Swivel Install Instructions

1.) Remove seat

- Use an 11/16 wrench to remove the bolt connecting your seatbelt to the seat platform.
- Use a 7/32 allen key to remove the factory bolts and washers from the sliding rails under seat. Keep these together to the side.
- Disconnect seat heater wiring if applicable.
- Lift the seat and remove it from the platform.

2.) Install swivel base

- Place the swivel adapter onto the seat platform with the handle on top facing forwards towards your windshield.
- Position it so that the factory holes in the seat platform each line up with a hole on the bottom tier of the swivel adapter. There are more holes than you will need to accommodate different model vans.
- Using a monkey wrench and the provided M8 bolts and washers, secure the swivel adapter to the seat base.

3.) Reinstall seat on the swivel adapter

- Place seat on top of the swivel adapter.
- Similarly to step two, align the holes on the rails of the seat with the holes on the top tier of the swivel adapter.
- Place the factory bolts and washers originally taken out of the seat base through the seat rail and corresponding holes on the swivel adapter.
- Begin threading a lock nut onto each one until you meet some resistance.
- Use a monkey wrench to hold the lock nuts in place while snugly tightening each bolt into them with an allen key.
- Reconnect the seatbelt to the seat platform.

Kick back and enjoy your brand-new swivel seat!